



MI-LIN931 RAM PROMASTER CITY PARTITION INSTALLATION GUIDE



MI-LIN932 RAM PROMASTER CITY PARTITION INSTALLATION GUIDE





BODYGUARD COMPOSITES

On behalf of Bodyguard and Malley Industries, congratulations and thank you for purchasing our interior van products.

Malley Industries is one of North America's premiere manufacturers of ambulances, patient transfer units and mobility vehicles. Bodyguard composite interiors are in all of these vans because they are rugged, safe, and easy-to-clean.

Bodyguard Van Liner products follow Malley's strict manufacturing process controls. With tens of thousands of our products in commercial and emergency vehicles throughout North America, Bodyguard's noise-reducing, lightweight interior products will provide years of protection while improving the fuel efficiency of your van.

Terry Malley

President & CEO



BODYGUARD COMPOSITES

MI-LIN931 & MI-LIN932

	QTY	DESCRIPTION	
	1	PARTITION PANEL	
A	2	M6-1.0 X 20MM DIN 933 CLASS 8.8 ZINC FINISH HEX CAP SCREWS	
B	4	M6 X 12MM FLAT WASHERS	
C	10	HEX HEAD #2 POINT 410 STAINLESS STEEL SELF-DRILLING SCREWS	
D	8	M8-1.25 X 25MM DIN 933 CLASS 8.8 ZINC FINISH HEX CAP SCREWS	
E	8	1/4" X 0.734" FLAT WASHERS	

SUGGESTED TOOLS:

M6 NUT DRIVER

M8 NUT DRIVER

1/4" NUT DRIVER (FOR SELF-TAPPING SCREWS)

A (1138565)
Hex Cap Screws



B (1140355)
Flat Washers



C (1131945)
#2 Point 410 Self-Drilling
Screws



D (1138616)
Hex Cap Screws



E (1133004)
Flat Washers



Ensure you have all required hardware and equipment prior to beginning installation.



WARNING: PRIOR TO DRILLING INTO THE VEHICLE, CHECK BEHIND DRILLING LOCATIONS FOR ELECTRICAL WIRES, FUEL/BRAKE LINES, AND OTHER CRITICAL COMPONENTS. ADJUST THE DRILLING LOCATIONS TO ENSURE THAT YOU AVOID CONTACT WITH THESE COMPONENTS. FAILURE TO DO SO CAN RESULT IN SERIOUS INJURY OR DEATH, AND CAUSE SEVERE DAMAGE TO THE VEHICLE'S FUNCTIONALITY.

DISCLAIMER: WHILE OUR PRODUCTS ARE PRODUCED WITHIN A MANUFACTURING PROTOCOL - ABS COMPOSITE PARTITIONS AND WALL LINERS COULD HAVE SLIGHT VARIANCES THAT OCCUR DURING THE MANUFACTURING PROCESS. VARIANCES IN THE VEHICLE MANUFACTURING PROCESS CAN ALSO AFFECT HOW OUR PRODUCTS FIT. IT MAY BE NECESSARY TO TRIM SOME AREAS TO ACCOMMODATE A BETTER FIT. SHOULD YOU HAVE QUESTIONS DURING THE INSTALLATION PROCESS, PLEASE CONTACT US.



1 Remove 2 OEM bolts in headliner.



2 Slide the partition panel into place so that it lines up against the B-Pillar and along the headliner.



3 Loosely insert washers (D) and bolts (E) at the bottom of the panel to secure the floor plate to the van floor.



4 Loosely insert bolts (A) and washers (B) at the top of the partition.



5 Loosely insert the self-tapping screws (C) in the remaining pre-drilled holes on the side of the partition.



6 When properly positioned, tighten all bolts.



7 Adjust the weather stripping.



8 Installion is complete.